



FLASH TEST REPORT

Execution

State of charge **52.3 %**
Date 28/05/2024 12:17:58
Executed by AURES Holdings

Vehicle

Brand Volkswagen
Model e-Up - 36,8 kWh
VIN WVVZZZAAZMD914622
Mileage 32,778 km

Analysis Result

AVILOO SCORE

92
/ 100

High voltage battery usage and history

Analysis of charging & driving behavior

65 / 70

High voltage battery performance

Analysis of cell voltages and module temperatures.

27 / 30

High voltage battery control unit

Check of signals and calculations of the battery management control unit.



Vehicle communication interface

Check of communication via the diagnostic interface.



Dr. Marcus Berger
CEO and Partner

DI Wolfgang Berger MBA
CSO and Founder

DI Nikolaus Mayerhofer
CTO and Founder



EXPLANATION OF THE BATTERY FLASH TEST

ANALYSIS METHOD

The analysis performed is a combined result of: The communication quality between the diagnostic hardware AVILOO Box and the on-board diagnostic interface of the vehicle. The live battery data and data that indicates the previous use of the high voltage battery, which is made available to the AVILOO Box by the battery management system during the measurement. The plausibility check and classification of the battery condition using the collected values and a comparison with the AVILOO Battery Cloud using Big Data algorithms.

FLASH TEST EXECUTION PROTOCOL

- 12:17:55 AVILOO Box connected.
- ✓ FLASH Test started.
- ✓ Vehicle detected.
- ✓ Starting data acquisition.
- ✓ Finished data acquisition.
- ✓ Analyzing data.
- ✓ Analysis completed.

DETAILED RESULTS OF PERFORMED CHECKS

Vehicle Information

VIN	WVWZZZAAZMD914622
Date	28/05/2024 12:17:58
Mileage	32,778 km

Measurements High Voltage System

Battery temperature	19.38 °C
Maximum cell temperature deviation	0.78 °C
Pack voltage	311.46 V
Maximum cell voltage deviation	12.45 mV
Peak current during check	-3.75 A
State of Health (SoH - read from car manufacturer)*	84.58 %

*The SoH shown here was not calculated by AVILOO but corresponds to the SoH read out from the battery management system and calculated by the manufacturer. AVILOO therefore does not guarantee the correctness of this SoH.

